






Donaldson.
FILTRATION SOLUTIONS

AIR FILTRATION DEVELOPMENT TOOLS

Prediction, Simulation & Analytical



$$E_I \propto St / (2Ku^2)$$



$$Pe^{-1} = \left[\frac{(1/2) \text{rms Brownian displacement}}{\text{fiber diameter}} \right]^2 = \frac{D}{D_f U}$$

Modeling Capability

- Proprietary, internally developed filter modeling software (Design Tool)
 - Allows performance predictions based on design variables
- Theoretical modeling based on
 - Fundamental filtration theory
 - Proprietary advanced filtration theory
 - Fundamental fluid mechanics
 - Computational fluid dynamic methods
- Scope
 - Filter media definition (a) and configuration (b)
 - Filter configuration (c)
 - Inertial separation configuration (d)
 - System configuration (e)
 - Environmental conditions
 - Validated with lab testing

Flow

FLUENT

- Computational fluid dynamics (CFD)
- Predicts airflow performance of components, including:
 - fluid flow, pressure loss, flow distributions, velocity distribution

MACROFLOW

- Predicts performance of systems by component
- Predicts fluid flow, pressure loss, flow velocity, flow rates, heat transfer rates
- Considers transient and steady-state flow

Structural

- ANSYS® and Abaqus™
- Finite Element Analysis (FEA)
- Stress analysis on components
- Modal sweep analysis to assess resonant frequencies

Acoustics

COMET

- Acoustic modeling software
- Enable prediction of transmission loss
- Considers impact of shell noise from system surfaces
- Includes impact of shell material
- Works in conjunction with ANSYS



Particle Characterization

- Scanning Electron Microscope
- Automated Particle Sizing and Counting
- Energy Dispersive Spectroscopy

Chemical Analysis Laboratory

- Temperature Programmed Desorption (TPD; TGA-MS) - loading and desorption profiles as a function of temperature
- Liquid Chromatography, Gas Phase
- Gas Chromatography-mass Spectrometry (GC-MS)
- Fourier Transform Infrared Spectroscopy (FTIR)
- Thermogravimetric Analysis (TGA)
- Differential Scanning Calorimetry (DSC)
- Breakthrough Test Benches
 - NO_x bench conducts dynamic evaluation of NO_x loading and regeneration
 - Ammonia bench used for dynamic evaluation of NH₃ loading and regeneration
 - Sulfur dioxide bench performs dynamic evaluation of SO₂ loading and regeneration.
 - VOC's bench dynamic evaluation of NO_x loading and regeneration

Acoustical Analysis

HEMI-ANECHOIC CHAMBERS (2)

- Used for transmission loss analysis

HEAD® ACOUSTICS

- Used for sound quality analysis
- Identifies objectionable sounds to human hearing

IN-CAB ACOUSTICS

- Allows analysis of in-cab noise based on cab design
- Considers affects of noise frequency



Donaldson Company, Inc.
 PO Box 1299
 Minneapolis, MN
 55440-1299
www.donaldson.com
www.donaldsonOEMfiltration.com

United States
 Canada
 Mexico
 Latin America
 Caribbean
 Brazil
 Europe

South Africa
 South East Asia
 Greater China
 Japan
 Australia
 India

Brochure No. F111302 (11/10)

© 2010 Donaldson Company, Inc. All rights reserved. Donaldson Company, Inc. reserves the right to change or discontinue any model or specification at any time and without notice. Printed in the U.S.A.